

3DP Type	Resin Type	Layer Height(mm )	Bottom Layer Count	Exposure Time/s	Bottom Exposure Time/s	Transition Layer Count	Waiting Mode During Printing	Rest Time Before Lift/s	Rest Time After Retract/s	Bottom Lift Distance/m m	Lifting Distance/m m	Bottom Retract Distance/m m	Retract Distance/m m	Bottom Lift Speed-mm/min	mm/min Lifting Speed	mm/min Bottom Retract Speed	mm/min Retract Speed
ELEGOO Mars 3/Mars 3 Pro	Implant Model Grey	0,05	4	4,0	35	8	Resting Time	0	0,5	4+4	4+3	6+2	5+2	60+90	90+150	120+60	180+90
	Implant Model Yellow	0,05	4	3,1	30	8		0	0,5	4+4	4+3	6+2	5+2	60+90	90+150	120+60	180+90
ELEGOO Mars 4 MAX	Implant Model Grey	0,05	4	2,9	25	8	Resting Time	0	1	4+4	4+4	6+2	6+2	60+90	60+120	120+60	180+90
	Implant Model Yellow	0,05	4	2,3	25	8		0	1	4+4	4+4	6+2	6+2	60+90	60+120	120+60	180+90
ELEGOO Mars 4	Implant Model Grey	0,05	4	4,6	40	8	Resting Time	0	0,5	4+4	4+3	6+2	5+2	60+90	90+150	120+60	180+90
	Implant Model Yellow	0,05	4	3,5	30	8		0	0,5	4+4	4+3	6+2	5+2	60+90	90+150	120+60	180+90
ELEGOO Mars 4 Ultra	Implant Model Grey	0,05	4	5,3	40	8	Resting Time	0	0,5	4+4	4+3	6+2	5+2	60+90	90+150	120+60	180+90
	Implant Model Yellow	0,05	4	4,1	35	8		0	0,5	4+4	4+3	6+2	5+2	60+90	90+150	120+60	180+90
ELEGOO Mars 5	Implant Model Grey	0,05	4	3,3	30	8	Resting Time	0	0,5	4+4	4+3	6+2	5+2	60+90	90+150	120+60	180+90
	Implant Model Yellow	0,05	4	2,6	25	8		0	0,5	4+4	4+3	6+2	5+2	60+90	90+150	120+60	180+90
ELEGOO Mars 5 Ultra	Implant Model Grey	0,05	4	3,6	30	8	Resting Time	0	0,5	/	/	/	/	/	/	/	/
	Implant Model Yellow	0,05	4	2,8	25	8		0	0,5	/	/	/	/	/	/	/	/
ELEGOO Saturn/Saturn S	Implant Model Grey	0,05	4	4,0	35	8	Resting Time	0	1	4+4	4+4	6+2	6+2	60+90	60+120	120+60	180+90
	Implant Model Yellow	0,05	4	3,1	30	8		0	1	4+4	4+4	6+2	6+2	60+90	60+120	120+60	180+90
ELEGOO Saturn 2	Implant Model Grey	0,05	4	3,6	30	8	Resting Time	0	1	4+4	4+4	6+2	6+2	60+90	60+120	120+60	180+90
	Implant Model Yellow	0,05	4	2,8	25	8		0	1	4+4	4+4	6+2	6+2	60+90	60+120	120+60	180+90
ELEGOO Saturn 8K	Implant Model Grey	0,05	4	6,4	45	8	Resting Time	0	1	4+4	4+4	6+2	6+2	60+90	60+120	120+60	180+90
	Implant Model Yellow	0,05	4	5,0	40	8		0	1	4+4	4+4	6+2	6+2	60+90	60+120	120+60	180+90
ELEGOO Saturn 3	Implant Model Grey	0,05	4	5,0	45	8	Resting Time	0	1	4+4	4+4	6+2	6+2	60+90	60+120	120+60	180+90
	Implant Model Yellow	0,05	4	3,9	35	8		0	1	4+4	4+4	6+2	6+2	60+90	60+120	120+60	180+90
ELEGOO Saturn 3 Ultra	Implant Model Grey	0,05	4	4,3	35	8	Resting Time	0,0	1,0	4+4	4+4	6+2	6+2	60+90	60+120	120+60	180+90
	Implant Model Yellow	0,05	4	3,4	30	8		0,0	1,0	4+4	4+4	6+2	6+2	60+90	60+120	120+60	180+90
ELEGOO Saturn 4	Implant Model Grey	0,05	4	2,9	25	8	Resting Time	0	1	4+4	4+4	6+2	6+2	60+90	60+120	120+60	180+90
	Implant Model Yellow	0,05	4	2,3	20	8		0	1	4+4	4+4	6+2	6+2	60+90	60+120	120+60	180+90
ELEGOO Saturn 4 Ultra	Implant Model Grey	0,05	4	3,8	35	8	Resting Time	0	1,5	/	/	/	/	/	/	/	/
	Implant Model Yellow	0,05	4	3,0	30	8		0	1,5	/	/	/	/	/	/	/	/
ELEGOO Saturn 4 Ultra 16K	Implant Model Grey	0,05	4	3,0	30	8	Resting Time	0	1,5	/	/	/	/	/	/	/	/
	Implant Model Yellow	0,05	4	2,4	25	8		0	1,5	/	/	/	/	/	/	/	/
ELEGOO Jupiter	Implant Model Grey	0,05	4	6,7	45	8	Resting Time	0	1	4+4	4+4	6+2	6+2	60+90	60+120	120+60	180+90
	Implant Model Yellow	0,05	4	5,3	45	8		0	1	4+4	4+4	6+2	6+2	60+90	60+120	120+60	180+90